

## TOOLS NEEDED



Edging  
Shovels



Hammer or  
Rubber Mallet



## TRENCH

- 1 Identify the placement of your edging and begin to trench your path. Use a half moon shovel or garden spade shovel for trenching. Create an approximately 3-inch deep by 2-inch wide trench by moving your shovel side to side and front and back.



## PLACE

- 2 Place edging into the trench. Edging should be approximately 1-inch above ground to properly separate your garden bed from your lawn.



- 3** Start at one end of the edging and insert stakes into the punched pocket holes.
- 4** Secure edging by hammering stakes into the ground with rubber mallet or hammer.



- 5** When connecting two edging pieces, overlap edging so punched pockets are vertically aligned.
- 6** Hammer stakes into ground with rubber mallet or hammer.



---

**FILL**

- 7** Backfill dirt along the back of your edging.

